EDGE Evolution Wall Wash








Grid Installation	2
Flanged (FL) Inaccessible Installation	3-4
Non-Flanged (NF) Inaccessible Installation	5-6
Spackle Flange Inaccessible Installation	7
Rotating Crossbar Inaccessible Installation	8


GRID EV3D-WV

INSTALLATION

GRID PREPARATION AND INSTALLATION

Prepare grid to the width needed to accommodate the fixture. Place fixture into grid opening and tie off fixture to support.





DIM G9/GS DIM G1 4" 4-1/4"


JOINING 3

Make wiring connections between fixtures, tap joining biscuit in to one fixture, slide fixtures together, and secure using joining bracket and four screws.

POWER

2


Remove Access Plate via one screw. Make wiring connections to building power and replace Access Plate.





SECURING TO GRID

Center fixture on grid, bend grid brackets over and fasten to grid.




EV3D-WW

FLANGED *(FL)* INSTALLATION




LAYOUT & DIMENSIONS

Rough in fixture opening and install 1/4" hardware (*by others*) according to tables to the right. Fixture length can be found on label inside fixture.



2 POWER

Remove Access Plate via one screw. Make wiring connections to building power and replace Access Plate.




ROUGH - IN		тн	THREADE		
DIM A	DIM B	LENGTH	DIM		
4-1/8"	3-5/8"	23″	3/4'		
Rough-in for len	ath is	24″	3/4'		
Row or Fixture L	0	35″	2-5/8		
	5	36″	2-5/8		
		47″	2-5/8		
		48″	2-5/8		
		59"	2-5/8		
		60″	2-5/8		
		71″	1-5/8		
		72″	2-5/8		
		83″	1-5/8		
		84″	1-5/8		
		05"	1 5/0		

THREADED ROD LOCATIONS				
LENGTH	DIM C	DIM D	DIM E	
23″	3/4"	21-1/2"	13/16″	
24"	3/4"	22-1/2"	13/16″	
35″	2-5/8"	29-3/4"	2-11/16"	
36″	2-5/8"	30-3/4"	2-11/16"	
47"	2-5/8"	41-3/4"	2-11/16"	
48″	2-5/8"	43-3/4"	2-11/16"	
59"	2-5/8"	53-3/4"	2-11/16"	
60"	2-5/8"	54-3/4"	2-11/16"	
71″	1-5/8"	66-3/4"	2-11/16"	
72″	2-5/8"	66-3/4"	2-11/16"	
83″	1-5/8"	78-3/4″	2-11/16"	
84″	1-5/8"	79-3/4"	2-11/16"	
95″	1-5/8"	90-3/4"	2-11/16"	
96″	2-5/8"	90-3/4"	2-11/16"	

3 INDIVIDUAL FIXTURE

Starting at one end remove wall wash module by pulling entire module out of fixture. Disconnect reflector wiring. Mount fixture through mounting slot to 1/4" hardware (*by others*).





EV3D-WW


FLANGED *(FL)* INSTALLATION


4 JOINING FIXTURES

Starting at one end remove wall wash module by pulling entire module out of fixture. Make wiring connections between fixtures, tap joining biscuit in to one fixture, slide fixtures together, and secure using joining bracket and four screws.

5 FINISHING

Re-install wall wash module by inserting extruded leg first then pinching in steel leg and inserting into housing. Push module into housing, you will hear the steel leg snap into place.






3D-WW insta

ROUGH - IN


LAYOUT & DIMENSIONS

Rough in fixture opening and install 1/4" hardware (by others) according to tables to the right. Fixture length can be found on label inside fixture.



2 POWER

Remove Access Plate via one screw. Make wiring connections to building power and replace Access Plate.




DIM A	DIM B	LENGTH
3-7/16"	3-5/8"	23″
Pough in for lor	ath is	24″
Rough-in for length is Row or Fixture Length + 3/8″		35″
	5	36″
		47"
		48″
		59"
		60"
		71″
		72″

THREADED ROD LOCATIONS				
LENGTH	DIM C	DIM D	DIM E	
23″	3/4″	21-1/2"	13/16″	
24"	3/4"	22-1/2"	13/16″	
35"	2-5/8"	29-3/4"	2-11/16"	
36″	2-5/8"	30-3/4"	2-11/16"	
47"	2-5/8"	41-3/4"	2-11/16"	
48″	2-5/8"	43-3/4"	2-11/16"	
59"	2-5/8"	53-3/4"	2-11/16"	
60″	2-5/8"	54-3/4"	2-11/16"	
71″	1-5/8″	66-3/4"	2-11/16"	
72"	2-5/8"	66-3/4"	2-11/16"	
83″	1-5/8″	78-3/4″	2-11/16"	
84"	1-5/8″	79-3/4″	2-11/16"	
95″	1-5/8″	90-3/4"	2-11/16"	
96″	2-5/8"	90-3/4"	2-11/16"	

3 INDIVIDUAL FIXTURE

Starting at one end remove wall wash module but pulling entire module out of fixture. Disconnect reflector wiring. Mount fixture through mounting slot to 1/4" hardware (*by others*).




NON-FLANGED (*NF*)


4 JOINING FIXTURES

Starting at one end remove wall wash module by pulling entire module out of fixture. Make wiring connections between fixtures, tap joining biscuit in to one fixture, slide fixtures together, and secure using joining bracket and four screws.



Re-install wall wash module by inserting extruded leg first then pinching in steel leg and inserting into housing. Push module into housing, you will hear the steel leg snap into place.








PAGE 6 of 8

EV3D-WW SPACKLE FLANGE (SF) INSTALLATION

DIMENSIONS AND LAYOUT


Rough in fixture opening according to the table below, fixture length can be found on label inside fixture.

(Note: Do not screw in to side of housing. Do not remove cross brackets until fixture is installed.)



POWER

Remove Access Plate via one screw. Make wiring connections to building power and replace Access Plate.




INDIVIDUAL FIXTURE

Mount fixture in rough-in opening by placing a screw behind each cross bracket along the length of the fixture and two on each end flange. Once mounted, remove cross brackets and discard. If individual fixture install lens.



Starting at one end remove wall wash module by pulling entire module out of fixture. Make wiring connections between fixtures, slide fixtures together, and secure using joining bracket and four screws. Once fixtures are joined re-in-stall wall wash module by inserting extruded leg first then pinching in steel leg and inserting into housing. Push module into housing, you will hear the steel leg snap into place.





EV3D-WW

ROTATING CROSSBAR (*RC*) INSTALLATION




LAYOUT & DIMENSIONS


Rough in Fixture opening according to table. Fixture length can be found on fixture label inside fixture.

POWER

Remove Access plate via one screw. Make wiring connections to building power and replace Access Plate.




ROUGH - IN MOUNTING DIM A DIM B FL 4-1/8" 3-5/8" NF 3-7/16" 3-5/8" Rough-in for length is Row or Fixture Length + 3/8"



INDIVIDUAL FIXTURE

Starting at one end remove wall wash module by pulling entire module out of fixture. Slide fixture into rough-in opening and rotate crossbar to lock in place using 1/4-20 screw inside fixture. If individual fixture replace wall wash module by inserting extruded leg first then pinching in steel leg and inserting into housing. Push module into housing, you will hear the steel leg snap into place.



4 JOINING

Starting at one end remove wall wash module by pulling entire module out of fixture. Make wiring connections between fixtures, tap joining biscuit in to one fixture, slide fixtures together, and secure using joining bracket and four screws. Once fixtures are joined re-install wall wash module by inserting extruded leg first then pinching in steel leg and inserting into housing. Push module into housing, you will hear the steel leg snap into place.

